



Molded Windfairing Install Instructions

Web: www.voyagerracks.com
email: info@voyageroffroad.com

Hardware:

- 2- Clamps
- 2- 5/16 Bolts
- 4- 5/16 flat washers
- 2- 5/16 nuts

You will need:

- 1- Box knife
- 1- Drill
- 1- 5/16 or 3/8 drill bit
- 1- Sharpie or Similar Pen
- 1- 1/2" wrench or socket

Thank you for your recent purchase!!

Installation Instructions:

1. Remove all packaging and inspect that all hardware was included.
2. Lower vehicle to access mode if available.

3. Place Clamps around front vertical supports, with holes facing forward:

4. Place windfairing on the front of the rack, so it fits tight. Position the clamps in the middle of the vertical support, and mark the center of the hole with a Sharpie, or other marking instrument. Repeat for driver and passenger side.



Front of Rack



Front of Rack



5. Remove Windfairing and Drill holes as defined in step 4, 1 for driver side and 1 for passenger side.
6. Place windfairing on rack.
7. Position Clamps under holes.
8. Insert Bolt and Washer into hole, through both holes in clamp.
9. Install Nut and Washer onto back side of bolt. Tighten.
10. Repeat for opposite side.

Your windfairing should now be fully installed and functional. If you have questions, or need assistance, call 941 235 7225, or call 941 421 9300 after hours. Thank you for your business.